

R6093U SPECIFICATION Ver1.2

Copyright © Microinfinity Co., Ltd.

MIBX-R001-1812SC-A290

<http://www.minfinity.com>

Contact Info.

EMAIL: support@minfinity.com, TEL: +82 31 546 7408 FAX: +82 31 546 7409

Contents

1. Functional Description	3
1.1. Overview	3
1.2. Block diagram	3
1.3. Features	4
1.4. System start-up	4
1.5. Installation	5
Mounting Information(Coordinate System)	5
2. Mechanical Specification	6
2.1. Dimensions	6
2.2. Specification	6
3. Interface Specification	7
3.1. Pin Configuration	7
3.2. Pin Definition	7
4. Electrical Specification	8
5. Performance Specification	9
6. UART Protocol	10
6.1. System information	10
6.2. Output format	10
6.3. Software reset	11
7. I2C Interface	12
7.1. DRDY(Data ready)	12
7.2. I2C protocol	13
8. Environmental Specification	14
9. Reflow Temperature Guideline	15
10. Packing Specification	16
10.1. Tray dimensions	16
10.2. Box Packing	17
11. RoHS Compliance	18
12. Handling Precaution	19
Contact Information	20
Corporate Office	20
USA	20

List of Figures

Figure 1: Functional diagram.....	3
Figure 2: The CruzCore R6093U coordinate system	5
Figure 3: Dimensions.....	6
Figure 4: Pin configuration of connectors.....	7
Figure 5: The CruzCore R6093U data packet format.....	10
Figure 6. DRDY signal example	12
Figure 7. I2C slave address	13
Figure 8. I2C data format.....	13
Figure 9: Temperature conditions at reflow	15
Figure 10 : Packing tray	16

List of Tables

Table 1: Mechanical specification.....	6
Table 2: Pin definition	7
Table 3: Absolute maximum ratings.....	8
Table 4: The CruzCore R6093U electrical characteristics.....	8
Table 5: The CruzCore R6093U performance characteristics.....	9
Table 6. Serial setting	10
Table 7: The CruzCore R6093U data fields description.	11
Table 8: Software reset command.	11
Table 9: Environment and mechanical test.	14

1. Functional Description

1.1. Overview

The CruzCore® R6093U is a 3 axis digital gyroscope and accelerometer. It's also working as attitude reference system that among others, can measure 3 axis angular rate, 3 axis acceleration and attitude(yaw is relative to initial orientation) under dynamic conditions. It is a highly compact, light, and fully self-contained module. Internally, the R6093U contains a 3 axis MEMS gyroscope and accelerometer, internal voltage regulator, signal processing circuitry and a RISC microprocessor running our patented error correcting algorithm. The R6093U uses an adaptive reduced order Kalman filter to reduce the errors that affect this type of sensors (i.e. bias drift, scale factor, asymmetry), as the result it produces very accurate stabilized angular rates and heading angle. The start-up time is less than 1 second, which is used to compute bias parameters; it does not require further calibration thereafter. The R6093U is the best 6 axis measuring solution for navigation applications.

1.2. Block diagram





Figure 1: Functional diagram.

1.3. Features

- I2C, UART output (selectable)
- Low power consumption
- Compact package
- Fast startup
- Fully self-contained
- 3 axis rate output
- 3 axis angle output
- 3 axis acceleration output



1.4. System start-up


The CruzCore R6093U startup time is less than one second. It internally compensates for errors due to changes in temperature. However, sudden temperature changes shortly after powering-on the unit can cause static rate errors. If such temperature changes are expected, we recommend leaving the gyro stationary for 5 seconds after startup. During startup time, it is required that the CruzCore R6093U is stationary on a level surface to obtain the best performance.

1.5. Installation


Mounting Information(Coordinate System)

To mount the CruzCore R6093U on your system, please refer to Figure 2, coordinate system. The R6093U must be mounted parallel to the ground, and the coordinates systems are different by mounting surface.

To obtains accurate attitude, please recall that mounting is very important and mounting error can cause attitude errors. If you want to use another coordinate system, please contact us.



When mounting on the **top** of customer PCB



When mounting on the **bottom** of customer PCB

Figure 2: The CruzCore R6093U coordinate system

2. Mechanical Specification

2.1. Dimensions




Figure 3: Dimensions

2.2. Specification

Table 1: Mechanical specification

Parameter	Specification	Tolerance	Comment
Length	25.0	±0.2	Unit: millimeter.
Width	20.0	±0.2	
Height	3.1	±0.3	
Weight	3.0	-1.5	Unit: gram

3. Interface Specification

3.1. Pin Configuration




Figure 4: Pin configuration of connectors

3.2. Pin Definition

Table 2: Pin definition

Pin No.	Pin name	I/O	Description
1	VDD	-	Main power (2.9V ~ 5.5VDC)
2	GND	-	Power ground
4	DRDY	O	In I2C mode, active-low data ready signal output.
8	GND	-	Power ground
11	TxD	O	UART transmit data
12	RxD	I	UART receive data
14	MODE	I	I2C / UART mode selection. For UART mode connect to GND or leave open. Tied to VDD for I2C mode.
16	SDA	I/O	I2C serial bus data.
17	SCL	I	I2C serial bus clock input.
18	nRST	I	System reset input. Must be driven by and open drain or equivalent output.
-	NA	-	Not available (leave open)

4. Electrical Specification

Table 3: Absolute maximum ratings

Parameter	Symbol	Value	Unit	Note
Power supply voltage	V _{DD}	-0.3 ~ 6.0	V	GND=0V
nRST Input voltage	V _{nRST}	-0.3 ~ 4.0	V	GND=0V
Port Input voltage	V _{IO}	-0.3 ~ 4.0	V	GND=0V
Operating temperature	T _{OPR}	-20 ~ +80	°C	
Storage temperature	T _{STG}	-40 ~ +85	°C	

Table 4: The CruzCore R6093U electrical characteristics

Parameter			Value			Unit
			Min.	Typ.	Max.	
Supply power	Input voltage	Operating	2.9		5.5	V
		Recommended		3.0		V
	Current	@ 3.0 V		13		mA
	Power consumption	@ 3.0 V		39		mW
I/O voltage	Pins for communication	Input "L"			1.2	V
		Input "H"	1.6			V
		Output "L"			0.4	V
		Output "H"	2.4			V
	nRST ¹	Input "L"			0.6	V
		Input "H"	2.4			V

* Data voltage levels can vary slightly due to internal load changes.

1. Use open collector logic when using the nRST function.

5. Performance Specification

Table 5: The CruzCore R6093U performance characteristics

Parameter		Value			Unit
		Min.	Typ.	Max.	
Start-up time ¹	Fast warm-up		0.5		sec
	Full alignment			5	min
Measurement range ²	Angular rate			± 250	deg/sec
	Acceleration			± 2	g
Bandwidth ³	Angular rate		12		Hz
	Acceleration		62.5		Hz
Yaw axis angular rate ⁴	Scale factor error		0.3		%
	Bias drift		10		deg/hr
Yaw axis relative angle ⁴	Proportional error		0.3		%
	Drift error		10		deg/hr
Roll, pitch accuracy ⁴	Static error		0.3		deg
	Dynamic error		0.7		deg
Resolution ⁵	Angular rate		0.01		deg/sec
	Angle		0.01		deg
	Acceleration		1		mg
Data rate ⁵	Adjustable		100		Hz

* The system must be installed in the correct position.

** @T_{OPR}=+25°C, V_{DD}=3.0V.

1. Full alignment: Total time that takes for full bias error calibration and temperature compensation. It is the worst case on condition that the temperature goes up suddenly without temperature compensation.
2. Other measurement range is available by customizing option(angular rate range is available up to 2000 deg/sec, acceleration range is available up to 16g). Please contact us
3. Other bandwidth is available by customizing option. Angular rate and acceleration each bandwidth are available up to 523Hz and 1kHz.
4. Guaranteed only under conditions: full alignment, steady-state room temperature, start-up on a level surface, under moderate dynamics (250 deg/sec angular rate).
5. Other data rate and resolution are available by customizing option.

6. UART Protocol

The CruzCore® R6093U provides UART rate, angle and acceleration outputs. The output format is shown in Figure 5 and is described in Table 7. The output consists on a 2 byte header, a 1byte index, a 4byte reserved, a 22 byte data section and 1 byte checksum. The checksum is the sum of all bytes in the data packet, excluding the header and checksum field. The output voltage level of the serial port is 2.8V. If you want another data format, please contact us.

Table 6. Serial setting

Baudrate	Data bits	Parity bit	Stop bits
38400	8	None	1

6.1. System information

When the CruzCore R6093U is powered up, it transmits the system information. For example:

```
%R6093U
%VX. XX-XX
```

The system information output can be changed without notice.

6.2. Output format

Following the system information the CruzCore R6093U starts transmitting the sensor data packages. The angular rate and angle provides measurements with 0.01 degree resolution, i.e. a 0.1 degree angle will be displayed as 10 (or 0x0A HEX).




Figure 5: The CruzCore R6093U data packet format

Table 7: The CruzCore R6093U data fields description.

Output data	Byte	Comments
HEADER	1-2	Hex value is: 0xA6A6
INDEX	3	0x00 ~ 0xFF
ANGLE ¹ (ROLL, PITCH, YAW)	4-9	Provided in 0.01 resolved deg.
RATE ¹ (ROLL, PITCH, YAW)	10-15	Provided in 0.01 resolved deg/sec.
ACCELERATION ¹ (X, Y, Z)	16-21	Provided in 1mg resolution.
RESERVED	22-25	
CHECKSUM ²	26	Sum of all bytes excluding the header.

1. First byte is the least significant.

2. CHECKSUM is 1 byte and the overflowed more than 1 byte is ignored.

6.3. Software reset

The CruzCore R6093U can accept reset input command.

Table 8: Software reset command.

Function	Command
Software reset	\$MIB,RESET*87

This command '\$MIB,RESET*87' resets the device. Refer to 1.4. for other details about sensor initialization.

7. I2C Interface

The CruizCore® R6093U operates as a slave that sends and receives data through an I2C 2-wire interface. The interface uses a Serial Data Line (SDA) and a Serial Clock Line (SCL) to achieve bi-directional communication between master(s) and slave(s). A master (typically a microcontroller) initiates all data transfers and generates the SCL clock that synchronizes the data transfer. The SDA line operates as both an input and an open-drain output. A pull-up resistor, typically 4.7 kΩ, is required on SDA. The SCL line operates only as an input. A pull-up resistor, typically 4.7 kΩ, is required on SCL. For simplifying data synchronization, the R6093U features a 100Hz data-ready signal (DRDY) which indicates when a new set of measured data is available.

7.1. DRDY(Data ready)

DRDY indicates when a new data is ready for retrieval. When DRDY transitions from high to low, new data are ready.




Figure 6. DRDY signal example

8. Environmental Specification

Table 9: Environment and mechanical test.

No.	Items	Test condition
1	High temperature storage	85°C x 120h
2	Low temperature Storage	-40°C x 72h
3	Temperature and Humidity cycling	25°C, 60%RH(4h) / 55°C, 95%RH(10h) / -30°C(2h) / 75°C(2h), 10cycles
4	Thermal shock	-40 °C ↔ 85 °C 1hour at each temperature, 10cycles
5	Drop	Free drop from 750mm height on a wooden board for 3 times
6	Vibration	10Hz to 55Hz amplitude 0.75mm, 55Hz to 500Hz acceleration 98m/s ² , 10Hz→500Hz→10Hz 15min/cycle, 6h(2h x 3directions)
7	ESD	R(330Ω) C(150pF), Contact discharge, 5times, 2kV

* After each test, there should be no visible damage and corresponds to criteria of the MIBX-R001-1701RC-A244(R6 Series Reliability Test Procedures).

9. Reflow Temperature Guideline

Recommended temperature conditions at reflow is shown on the following Figure 6.




Figure 9: Temperature conditions at reflow

Pre-heating temperature: +170°C	Pre-heating time: 100sec
Heating temperature: +220°C	Heating time: 40sec
Peak temperature \leq +250°C	

10. Packing Specification

10.1. Tray dimensions




Figure 10 : Packing tray


10.2. Box Packing




R6093U



- 40pcs/Tray (4x10)
- Stack 5 tray (including one empty tray)
- Totally 160pcs (40x4)



- Vacuum sealing
- Cushion bar and bubble sheet
- Totally 320pcs (160x2)



320pcs/Inner box



- 1,280pcs/Carton (320x4)
- Stack 4 inner box

11. RoHS Compliance

The CruzCore® R6093U module and its homogeneous materials comply with European Union's restriction on use of hazardous substances("RoHS") Directive, 2002/95/EC.

12. Handling Precaution

This product includes MEMS sensor. Please handle carefully paying attention to the next points. We recommend to avoid mechanical shocks during handling and transport. The excessive shock may make the characteristic of product change or deteriorate. So please set up your site so that the shock becomes as small as possible. Please be sure to check the characteristics in case that the product is dropped from the desktop and too much shock is applied to the products. This product has built-in protections against high electrostatic discharges or electric fields. However, when the excessive static electricity is charged, product may break. So please use conductive ones for packing and carrying containers.

Contact Information

Corporate Office

MicroInfinity Co., Ltd.
8F KANC, 109 Gwanggyo-ro
Yengtong-gu Suwon-si
Gyeonggi-do, 443-270, Korea
Tel : +82 31 546 7408
Fax : +82 31 546 7409
Email: support@minfinity.com

USA

P.O. Box 131284
Ann Arbor, MI 48105, USA
Tel : +1 734 223 5904
Fax : +1 866 400 3125
Email: usa.support@minfinity.com

Homepage: <http://www.minfinity.com>